


Printable Biomaterials

MAX-PLANCK-INSTITUT
FÜR POLYMERFORSCHUNG




QUESTIONS



Join at menti.com | Code: 7744 9634





USES OF BIOMATERIALS



Food Tissue Engineering



Medical Implants




Drug Delivery



Biosensors




Wound Healing



Tissue Engineering

BUILDING BLOCKS


BIO




MATERIALS

DEVELOPMENT OF BIOMATERIALS RELIES ON 4 IMPORTANT FACTORS

Cells



DESIGN & FUNCTIONALITIES OF BIOMATERIALS



BIOMATERIALS MARKET



GMI Global Market Insights
Insights to Innovation

MARKET STATISTICS

Market Size
(2023)

\$123.80 Bn

CAGR
(2024-2032)

12.6%

Market Value
(2032)

\$360.70 Bn

REGIONAL ANALYSIS



North America
Market Share (2022)

37.3%

MARKET SEGMENTATION

Polymeric Biomaterials
Segment
CAGR 2023-2032

13.1%

Cardiovascular Segment
Market Share
(2022)

23.3%

Orthopedic Segment
Market Share
(2022)

17.8%

Market by Region, 2019

- North America
- Europe
- Asia Pacific
- Latin America
- Middle East & Africa




Key Market Findings




Deployment of 3D Printing
in Tissue Engineering
to Boost Demand

Biofabrication


What is Biofabrication?




Biofabrication is the production of complex biological products, tissues, and organs through 3D printing, electrospinning, and other advanced techniques.



BIOENGINEERING RESEARCH: ADVANCING RAPIDLY




1000 μm



BIOENGINEERING RESEARCH: ADVANCING RAPIDLY



3D BIOPRINTED OF EDIBLE FISH




(BIO)PRINTING IN KLINICS



3D BIOPRINTED HEART CONSTRUCT




3D (BIO)PRINTING PROCESS



(BIO)INK FROM POLYMERS

Biomaterial



Natural polymers are large, organic molecules derived from living organisms, such as proteins, polysaccharides, and nucleic acids, that play essential roles in biological processes.

Advantages:

- Biocompatibility
- Biodegradability
- Renewability
- Versatility
- Enhanced cell interaction



Cellulose




DNA

Synthetic polymers are man-made compounds created through chemical processes that combine small molecules (monomers) into long, repeating chains, enabling a wide range of applications.

Advantages:

- Control over properties
- Consistency in production
- Tailored functionalities
- Cost-effectiveness
- Durability



Rubber



Epoxy




Polyester


USE OF BIOINFORMATICS TO BIOMATERIAL DESIGN

Bioinformatics can reveal:


- **Protein sequences** for biomaterial scaffolds (e.g., silk, collagen, elastin-like polypeptides)
- **Cell-matrix interaction motifs** (RGD, YIGSR, IKVAV) obtained from protein databases
- **Enzyme cleavage sites** to design degradable hydrogels
- **Gene expression data** to tailor biomaterials for specific cell types
- Material **biomechanics and processability**



(BIO)INK : MODULAR DESIGN



(BIO)INKS: HYDROGELS




Advantages of using hydrogels:

- Biocompatibility
- High Water Content
- Adjustable Mechanical Properties
- Porosity
- Bioactive Molecule Incorporation
- Printability


BIOINK VS BIOMATERIALS INK

BIOINK


Cells as mandatory component



Optional: combined with materials



Processing with a
biofabrication technique





BIOINK VS BIOMATERIALS INK


BIOMATERIAL INK

Additive manufacturing of biomaterials as inks



Seeding of the scaffolds with cells






BIOINK CHARACTERISTICS


Maintain Cell Viability

Protection from shear stress




Protected cells
Sheared cells

Mass transport (diffusion)




★ Biomolecules
★ Nutrients

Adhesion sites







Allows cells to interact
with the matrix



DESIGN CONSIDERATIONS FOR HYDROGEL-BASED BIOINKS




Gel-phase bioink rheological behavior





BIOINK DEVELOPMENT



IDEAL BIOFABRICATION WINDOW




(BIO)INKS CROSSLINKING




Adv. Mater. (2013), **25**, 5011–5028

(BIO)INK CHARACTERIZATION: PRINTABILITY VALUE



3D (BIO)PRINTING TECHNIQUES

INKJET



A tiny heater rapidly vaporizes a small portion of bioink to form a droplet.

A piezoelectric actuator generates pressure pulses to eject droplets.


AK Bloom

Characteristics:

- **Droplet-based deposition**, highly controlled.
- **High resolution** (tens of micrometers).
- **Low viscosity bioinks** are required.
- **Non-contact printing**, reducing contamination risk.
- **Limited to low cell density**, as high viscosity or cell density can clog the nozzle.

3D (BIO)PRINTING TECHNIQUES

EXTRUSION



AK Landfester
&
AK Weil

Pressurized air pushes bioink through a nozzle.

A piston pushes the bioink.


A rotating screw pushes bioink.

Characteristics:

- **Continuous filament deposition**, rather than discrete droplets.
- **Compatible with higher viscosity bioinks** and higher cell densities.
- **Lower resolution** than inkjet (100–500 μm).
- **Shear stress** on cells can be higher, potentially affecting cell viability.
- Can print **larger 3D structures**.


EXTRUSION BASED (BIO)PRINTING

Extrusion-based bioprinting




**Shear thinning
(DIW)**

Pressure based
extrusion of bioink
through a syringe.




**Co-axial
extrusion**

Deliver bioink and a
crosslinking solution
using separate nozzle.



**Printing in
coagulation bath**

Extruding bioink
directly into a
coagulation bath that
triggers its gelation.



**Freeform reversible
embedding**

Extruding bioink into a
pseudoplastic or
granular bath.

Type of bath:




**Granular
(microparticles)**



**Colloidal
(supramolecular
assembly)**

3D (BIO)PRINTING TECHNIQUES

MICRO-VALVE




Characteristics:

- **Droplet-based**, similar to inkjet but can handle higher viscosities.
- **Moderate resolution**.
- Non-contact, reducing contamination risk.
- Good for **cell-laden bioinks**, as shear stress is lower than extrusion.

Solenoid-controlled plunger or valve releases bioink droplets under pressure.

3D (BIO)PRINTING TECHNIQUES

LASER



Laser-Induced Forward Transfer (LIFT)


A laser pulse hits an energy-absorbing layer, propelling a droplet of bioink from a donor substrate to a receiving substrate.

Characteristics:



- **High resolution** (10–50 μm).
- **Non-contact**, avoiding nozzle clogging.
- Can handle **very viscous bioinks**.
- Can deposit **single cells or small cell clusters** with high precision.
- More complex and expensive than other methods.

2-PHOTON 3D MICRO(BIO)PRINTING

HIGH RESOLUTION PRINTING IN μm SCALE



500 μm




2 Photon 3D Microprinting:


- Reproducible
- High Resolution
- ECM and Tissue microstructures can be simulated

3D (BIO)PRINTING TECHNIQUES

Melt Electro-Writing (MEW)



Molten polymer is extruded under high voltage and precisely controlled stage movement, allowing fibers to be deposited in defined patterns.





Characteristics:

- **Fiber-based**, typically 1–50 μm in diameter.
- **Highly controlled fiber placement**, enabling 3D microstructures.
- **Solvent-free**, safer and environmentally friendly.
- Produces smooth, **uniform fibers with tunable porosity**.
- Ideal for tissue engineering scaffolds and microstructured biomedical devices.

3D (BIO)PRINTING TECHNIQUES

Electrospinning




High-voltage electrostatic field draws a polymer solution or melt from a needle tip toward a grounded collector, forming fine fibers.

AK Landfester

Characteristics:

- **Fiber-based**, mainly nanoscale fibers (100 nm – few μ m).
- Fibers are usually **randomly oriented**, but alignment possible with special collectors.
- **Solution-based**, requires solvent evaporation.
- High porosity, **limited control over exact fiber placement**.
- Suitable for filtration, drug delivery, wound dressing, and scaffolds.


BIOFABLAB RESEARCH FOCUS



We develop **life-inspired biomaterials**, by organizing molecules into higher-order assemblies and tuning their interfaces!



Multifunctional Biomaterials



We develop **dynamic environments** that protect and interact with cells, ensuring survival and functionality during and after printing!

Dynamic Bioinks




We develop **adaptive molecular systems** that evolve from molecular design into functional, **3D life-like model systems**, that do not only host cells but also communicate, respond, and evolve with them!




Adaptive Prototypes of Life


BIOMATERIALS AND BIOAPPLICATIONS



© ChatGPT



© ChatGPT



Biomaterials

Synthesis of Nature-Inspired Materials

Physicochemical Characterization

Rheological - Mechanical Characterization

Electrical Characterization

(Bio)Fabrication

Extrusion Bioprinting

Microprinting

Light-assisted 3D printing

Electrowriting/Electrospinning/Electrosprayin
g

Bioapplications

Cell-Material Interactions

Cell/Tissue Adhesion


Biomolecule Release

In vivo Experimentation



3D PRINTABLE HYDROGELS: TISSUE ENGINEERING

(Bio)printing


Pneumatic, piston
or screw driven





Bone Engineering



Neural Engineering



Heart Engineering



Xin Wei



Ayaan Khan



Till Grandjean




Alex Reitz

Feng; Zheng; Bhusari; **Villiou**, et. al., *Adv. Funct. Mater.* **2020**
Włodarczyk-Biegum; Paez; **Villiou**, et al. *Biofabrication* **2020**
Włodarczyk-Biegum; **Villiou**, et al. *ACS Biomater.Sci.Eng.* **2022**


Wei; Grandjean; Reitz, Ritz, Landfester*, **Villiou***. Manuscript in preparation **2025**

3D PRINTABLE HYDROGELS: CELL-MATERIAL INTERACTIONS


Light-assisted 3D printing




Cell – materials Interactions




Cell Migration



Manipulation-Migration




3D Cell Reconstruction



Xin Wei

PRINTING OF FUNCTIONAL ARTIFICIAL CELLS





Dr. Tsvetomir Ivanov Lukas Hein

MULTICOMPONENT PRINTING: BIOSENSORS



Daimler and
Benz Foundation



Glucose Biosensors




Hydrogel-gated OECT



Lukas Hein Dr. Renan Colucci



Glucose [mmol L⁻¹]

O₂ Sensor for Cells






















Tuning the Hypoxia

$I_{exc} = 660 \text{ nm}$



Maria Micheva Dr. Stanislav Balouchev



INTRODUCTION TO COMPUTER AIDED DESIGNING (CAD)




USE THE DESIGNS FOR 3D Printing



Problem?



Solution



Planning: What is the problem?


Concept: How can I solve the problem?

Drafting: What solutions are possible?

Design: What is the final product?

Computer-Aided Engineering Tools

COMPUTER AIDED ENGINEERING



COMPUTER AIDED DESIGN

- **Replaces traditional hand drafting**

Faster, more accurate, and easily editable compared to manual drawings.

- **Used to design, draft, and produce digital models**

Supports the entire workflow from concept sketches to detailed production drawings.

- **Applied across nearly all industries**

Architecture, construction, engineering, automotive, aerospace, manufacturing, product design, and more.

- **Creates precise 3D models**

Allows visualization of shapes, dimensions, assemblies, and internal components.

- **Enables realistic materials and lighting**

Produces photorealistic renderings for presentations, marketing, and client approvals.

- **Simulates real-world performance**

Includes stress, motion, heat, flow, and structural analysis to validate designs before physical prototyping.

- **Provides comprehensive design documentation**

Generates technical drawings, BOMs (Bill of Materials), reports, and files for patents, manufacturing, and communication.



STRESS SIMULATION IN CAD: USE FINITE ELEMENT ANALYSIS (FEA)

- **Non-destructive virtual testing**

Evaluates strength, durability, and failure points without damaging physical prototypes.

- **Simulates real usage and application conditions**

Models loads, pressure, vibration, impact, temperature, and other operational forces.

- **Identifies weaknesses early in the design stage**


Reveals stress concentrations, deformation, and potential failure zones before manufacturing.

- **Optimizes materials and geometry**


Helps reduce weight, increase strength, and improve overall performance and safety.

- **Reduces cost and development time**

Minimizes the need for multiple physical prototypes and shortens the design-validation cycle.



Fixed Constraint:1



1st Principal Stress

STRESS SIMULATION - FINITE ELEMENT ANALYSIS (FEA)

TOPOLOGY OPTIMISATION IN CAD

- Uses computational algorithms to automatically improve a model's mechanical performance.

- **Enhances strength-to-weight ratio**

Adjusts geometry to achieve maximum stiffness or strength with minimal material

- **Removes non-contributing material**




Identifies and eliminates excess areas that do not improve structural performance.

- **Generates efficient, lightweight structures**

Produces organic, high-performance shapes ideal for aerospace, automotive, and additive manufacturing.

- **Supports rapid iteration and redesign**

Integrates directly into CAD workflows for quick evaluation and modification of optimized designs.



WHAT TO TAKE INTO ACCOUNT?

The design


- Does it look nice? Beautiful? Attractive for science/customers?

Costs

- Time of production
- Material: type and quantity

Technical specification

- Does it follow the rules, the size, materials, etc.
- How is it produced? Is it possible to produce it the way it is designed?



COMPUTER AIDED DESIGNING (CAD)

- Create **3D or 2D models**
- **Supports multiple file formats**, examples: .ipt, .iam, .step, .dwg for design and sharing.
- Common CAD software: **Autodesk Inventor/ Fusion, Tinkercard, SolidWorks...**



CAD SOFTWARES

Commercial software [edit]

- AC3D
- Alibre Design
- ArchiCAD (Graphisoft)
- AutoCAD (Autodesk)
- Autodesk Inventor
- AxSTREAM
- BricsCAD
- CATIA (Dassault Systèmes)
- Cobalt
- CorelCAD
- Fusion 360 (Autodesk)
- IntelliCAD
- IRONCAD
- KeyCreator (Kubotek)
- Landscape Express
- MEDUSA
- MicroStation (Bentley Systems)
- Modelur (AgiliCity)
- Onshape
- Promine
- PTC Creo (successor to Pro/ENGINEER)
- PunchCAD
- Remo 3D
- Revit (Autodesk)
- Rhinoceros 3D
- Siemens NX
- SketchUp
- Solid Edge (Siemens)
- SolidWorks (Dassault Systèmes)
- SpaceClaim
- T-FLEX CAD
- TranslateCAD
- TurboCAD
- Vectorworks (Nemetschek)

Not the best user interface
but its ok


Open-source software

- BRL-CAD
- FreeCAD
- LibreCAD
- OpenSCAD
- QCAD
- Salome (software)
- SolveSpace
- CAD Sketcher

COMPUTER AIDED DESIGNING (CAD)



- Create **3D or 2D models**
- **Supports multiple file formats**, examples: .ipt, .iam, .step, .dwg for design and sharing.
- Common CAD software: **Autodesk Inventor/ Fusion, Tinkercard, SolidWorks...**
- **Prepares models for 3D printing**: Always export as **STL-file** which converts geometry into a triangle mesh.
- **Control STL export quality**: Adjust resolution, deviation, and accuracy for smoother prints.
- **Speeds up prototyping and reduces errors**: Enables fast iteration before manufacturing.



3D PRINTING WORKFLOW: GENERAL STEPS

Designing your structure on the computer (CAD)

→ export your model commonly as **STL-file**

Choosing a **suitable type of 3D printer**

→ material restrictions? Size of final structure? Costs ? ...?


Preparing a **print job file via the printers slicing software**

→ import the STL-file; set printing parameters (Temperature, ...)

Start print job and **cross your fingers for it to succeed**



Take out your printed part
→ sometimes post printing processes are required





AUTODESK INVENTOR GOLDEN RULES


- **Verify your starting planes and directions**

Ensure visibility is correct; create additional reference planes when needed.

- **Always sketch in 2D first: Use "Sketch"**

Build clean sketches, then apply 3D operations like extrude, revolve, or sweep.

2D drawings






AUTODESK INVENTOR GOLDEN RULES

- **Verify your starting planes and directions**


Ensure visibility is correct; create additional reference planes when needed.

- **Always sketch in 2D first**


Build clean sketches, then apply **3D operations like extrude, revolve, or sweep: Use "Create"**




Extrude




Revolve



Sweep



Loft





AUTODESK INVENTOR GOLDEN RULES

- **Fully define every sketch**

Use dimensions and constraints to avoid errors and make later modifications easier.

- **Maintain proper sketch origin placement**

Size and position your geometry relative to the origin; center sketches whenever possible.

- **Use construction lines for alignment**

Improve accuracy, symmetry, and constraint management.

- **Reuse sketches when appropriate**

Share sketches to avoid redundant work and maintain design consistency.


- **Use quick tools efficiently**

The "M" key helps with measurement and verification.



AUTODESK INVENTOR GOLDEN RULES

- **Leverage pattern and mirror features: Use “Pattern”**
Speed up repetitive geometry creation and ensure perfect symmetry.






AUTODESK INVENTOR GOLDEN RULES

- **Leverage pattern and mirror features**

Speed up repetitive geometry creation and ensure perfect symmetry.

- **Combine multiple solids when needed: Use "Modify"**

Final part should contain **one single solid body** unless intentionally modeling multi-body parts.



Move, Fillet



AUTODESK INVENTOR GOLDEN RULES

- **Adjust visual style**

Shaded, wireframe, or hidden-line views can help detect issues.

- **Use section views**

Half-section or full-section views help inspect internal geometry.

- **Export images when documenting your work**

Useful for reports, presentations, or reviews.




- **Use ESC key frequently**

Quickly cancel unwanted commands or actions.

Prevent accidental operations or sketch edits.

Helps you reset the cursor and navigate faster in the CAD environment.

AN INTRODUCTION TO TINKERCARD



WHAT IS TINKERCARD?

- Free, browser-based 3D-design tool
- Log in by visiting tinkercad.com
- Sign in using Google or Apple
- Create a new design and get creative!



TINKERCAD...THE EASIEST OPTION!!

Join now: <https://www.tinkercad.com/>

 **AUTODESK**
Tinkercad

Tinker ▾ Gallery Learn Teachers Resources ▾

Q Log In Sign Up


We're celebrating 100M Tinkerers!

Thanks for making Tinkercad the go-to place to design, learn, and play. Here's to the next 100 million creators!


[Read blog post](#)




THE HUD




THE HUD




THE HUD




THE HUD



CREATING YOUR 3D-DESIGN





CREATING YOUR 3D-DESIGN





CREATING YOUR 3D-DESIGN

Align the geometries



Group the geometries



EXPORT YOUR DESIGN...

as an STL file!

